



## STABILIZER

## PART LIST

PART	QTY	S / N	DESCRIPTION
1	6	6-T-1-2	Stabilizer rib
2	1	6-T-1-3	Front spar
3	2	6-T-1-5HD	Front spar cap doubler
4	1	6-T-1-4	Rear spar
5	1	6-T-1-6HD	Rear spar upper doubler
6	1	6-T-1-7HD	Rear spar lower doubler
7	1	6-T-2-6HD	Rear spar shim
8	1	6-T-2-3	Rear spar attachment
9	1	6-T-1-1L	Left end rib
10	1	6-T-1-1R	Right end rib
11	2	6-T-1-8	Tip rib
12	4	6-T-1-L	O / B rib angle
13	1	6-T-2-2L	Left attachment doubler
14	1	6-T-2-1L	Left front spar attachment
15	1	6-T-2-2R	Right attachment doubler
16	1	6-T-2-1R	Right front spar attachment
17	1	6-T-2-4	Stabilizer skin
19	1	6-T-1-50	
20	2	6-T-1-51	Stabilizer tip